



Slow Up Roller Shade (single) Installation Instructions

1. *Do not remove shrink wrap from shade until unit is installed.*
Note: Shade should be positioned with the fabric going over the top and down the back of the shade.

2. Install mounting brackets at desired balance. Clear plastic button is front of the bracket. Clip back of head rail on to mounting brackets and snap into place.

Sidemark – limits are pre-set at factory.

3. Controls:
Right side = Positioning Device. The Positioning Device controls the upper limits (stopping point). To make an adjustment, turn dial clockwise (right side end view) to lower the limit.

Left side = Tensioning Device. Tensioning Device controls the upward speed.

To make an adjustment, turn dial clockwise (left side end view) to increase speed.