

Installation Guide



Step One: Using the Bracket Mounting Template shown above, mark the location on the wall for the mounting screws.



Step Two: Drill two pilot holes per side for each bracket (3/16" drill bit) insert wall anchors and attach to wall with screws provided.



Step Three: Hang draperies on the rod and place into brackets.



Step Four: Finished!