








CLUTCH CELLULAR SHADE INSTALLATION INSTRUCTION

Number of parts included for each shade:

Shade width	# of Brackets	Screw
5 ~ 47.9"	2	4
48" ~ 72.9"	3	6
73" ~ 95.9"	4	8
96" ~ 120.9"	5	10
121" ~ 144"	6	12




Outside Mount



Inside Mount

WARNING/ ADVERTENCIA



Window blind cord can STRANGLE your child. To prevent strangulation, purchase cordless products or products with inaccessible cords.

La cuerda de la persiana puede ESTRANGULAR a su niño.
Para evitar el estrangulamiento, compre alternativas cuerda o productos con cuerdas inaccesibles.

!IMPORTANT NOTE: CORD TENSIONER MUST BE MOUNTED ON THE WALL TO ENSURE SAFE OPERATION.

Please allow 24 hours for your shade to drop to its actual height when first installed due to the nature of the fabric.