

# Installation Instructions for Honeycomb Cellular Shades

## **Bracket Installation:**

Shades are shipped with the required number of brackets for proper installation. End brackets should be located approximately 2-1/2" from each end. Depending on the width of the shade, additional brackets may be necessary evenly spaced between the two end brackets.

Using the installation bracket as a template, measure and mark the center lines. When mounting brackets, make sure they are in line and level.

## **Inside Mount:**

The brackets are mounted flat against the top sill surface. Place the screw through the hole in the top of the brackets. To fully recess the shade requires a flat surface with a minimum depth of 2-1/2". Shallow mounting requires 1-1/2" minimum.

## **Outside Mount:**

The brackets are mounted with two screws through the back end of the brackets flat against the window molding or the wall above the window. The brackets require a minimum surface 1" high.

## **Hanging the shade:**

Unwind the cord from the shade but keep the rubber band around the shade stack.

1. Hold the shade up near the brackets and insert the front edge of the bracket into the front groove of the rail.
2. Push the rail back and up until the back edge of the bracket are inserted in the back groove of the rail.

## **Side Mount:**

1. Insert the brackets into the shade before installing. Side mount brackets slide under the two grooves on the front and back of the headrail. You must slide out the lift mechanism approximately 1/4" in order to insert the bracket. The bracket goes over the lift mechanism and then slides into the headrail grooves. Slide the lift mechanism and the bracket back into place.
2. Lower the shade.
3. Mount the brackets by placing the screw through the hole on the side of the bracket. Side mount brackets screw into the side frame of the window.

## **Cordlock Operation:**

To lower or release shade, pull the cord inward toward the center of the shade.

To raise or lock the shade, pull the cord straight down. Pull outward toward the edge of the shade to lock the shade in place.